


# WARMAWEAR HEATED UNDER VEST USER MANUAL

THANKS FOR PURCHASING OUR PRODUCTS, PLEASE READ THE USER MANUAL BEFORE USE



## PRODUCTS SPECIFICATION

Materials: 85% polyester, 15% spandex

Rating voltage: DC/5.0V

Rating power: 8W±1W

Temperature level: H, M, L

| H (Red LED)  |                  | M (Blue LED) |                  | L (Green LED) |                  |
|--------------|------------------|--------------|------------------|---------------|------------------|
| Temperature  | Battery use time | Temperature  | Battery use time | Temperature   | Battery use time |
| up to 50±5°C | up to 2.1±0.2H   | up to 45±5°C | up to 2.8±0.2H   | up to 40±5°C  | up to 4.2±0.2H   |

REMARK: 1. Above battery use time is tested by 5.0V/5000MAH power bank


## NOTICE

Notice:

- ① Red/Blue/Green LED if all flash then then the device will automatically switch off. Possible fault.
- ② Green LED flash 3 times then auto off, means the products is out of circuit.
- ③ 3 hours timer-will auto off after 3 hours use

## INSTRUCTION

1. Press and hold silicon button for 3 seconds the LED will flash: RED-BLUE-GREEN, and stop at RED. The heater is now on high setting.



2. Press silicon button to select the temperature.



3. Turn off the heater : press silicon button and hold for 3 seconds, LED will switch off.

## WASHING INSTRUCTION

- ※ Can be dry cleaned.
- ※ Wipe surface with damp cloth.
- ※ When hand washing in water, please cover the USB plug with the rubber lid for protecting the plug from water.



## ⚠ WARNING

1. Do not submerge in water.
2. Take out the power bank when not in use
3. Assure the power bank have been charged before use.
4. Please use good quality power bank. It is regular that power bank may turn slightly warm during working. If the power bank quality not good, it may heat up more than 60°C, please turn off the power immediately in this condition.
5. Do not wear directly on skin.