

PestBye® Animal Deterrent – PB0043

Thank you for purchasing the
PestBye® Animal Deterrent – PB0043

This device is effective in deterring numerous garden pests including Birds, Deer, Foxes, Rodents and Cats.

How does it work?

If the unit is set to sensor mode, the motion infrared sensor detects a warm body movement in the field of view and activates the selected functions which act as a deterrent to garden pests.

How to use:

1. Install batteries or plug in the mains adaptor.
2. Install the unit using the keyhole slots on the back to attach it to a wall or post using screws or nails.

It's important to aim the device at the problem area, avoiding any areas with high level of human activity to avoid draining the batteries.

The lens should be between 1m to 1.4m from the ground for optimum range.

Ultrasonic sound won't work through walls, so ensure the device has an un-obstructed view of the effected area.

3. Use the On/Off Switch to power up the unit.
4. Set the Sonic / Ultrasonic and Strobe switch:

Both the Sonic/Ultrasonic and Strobe function switch have the same three settings:

OFF: Function will be turned off

SENSOR: The function will be triggered for 10 seconds when the device detects movement. After which it will reset and await the next detection.

CONT: The function will activate flash continuously. It is advisable only to use this mode when the unit is in operation with the mains adaptor.

5. Set the Frequency. The frequency dial is a sliding scale from audible (left) to inaudible (right).



Handy Tip: Change the sonic / ultrasonic frequency regularly using the frequency switch. The variation will prevent the pest from becoming accustomed to the sound and will increase the devices effectiveness!

6. Adjust infrared motion sensor sensitivity with the Sensitivity switch to affect how far away from the unit movement will be picked up.



Handy Tip: Reducing the sensitivity to only cover the affected area can aid battery life by preventing the unit from detecting too far and activating too often (if you have a pathway at the end of the area for example).

7. Use the test switch to check the unit is functioning and batteries are not flat.

How quickly will it work?

Occasional visitors will usually stop within 7 days, however if the pests visit the area habitually, it can take 2-4 weeks before you start to see the effect. It's important to keep the device running during this time, it can be difficult to break the animals' routine but given the chance you should find this unit to be effective.

Specifications:

- Outdoor Use
- Dimensions: 170 x 154 x 107mm
- Weight: Approx 340g
- Frequency: 1-30 KHz (audible), 90KHz (ultrasonic)
- Detecting Area: up to 35m in 120° angle
- Power: 4xD Batteries (Not Included) Or 64/500MA Mains adaptor (included).

