

ABOUT TIME



Congratulations on your purchase of our About Time clock, never again will you have to worry about remembering to move the clocks forward or back. Keep perfect time all day every day with these unique and intelligent clocks.

Radio Controlled Wall Clock Instructions

Radio Controlled Time Positioning

Insert 1x AA battery at the back of the clock. The clock hands will move and stop at 12:00 O'clock. (If the hands carry on moving past 12:00 O'clock, do not panic, they will run another cycle until they all stop at zero position, which is 12:00 O'clock.)

The clock will now begin to receive the time automatically; this can take between 3 to 10 minutes. If signal is received successfully then the hands will adjust to the correct time and work as normal. Otherwise, if the time is not successfully found, then the clock will return to normal operating mode with the incorrect time. However, when the next hour is reached, the clock will repeat the above action again until it receives the correct time signal. If signal is still not found, the clock will repeat the process up to 14 times until exiting the function.

Setting the time manually

Press the left M.SET button and hold for 3 seconds to enter the manual mode. You can now set the time manually. In this setting, each time you press the M.SET button the hand will move forward one minute. If you stop pressing the M.SET button for 7 seconds, then the manual setting function is over and the clock's time will run as usual.

Force Receiving

Whilst the clock is running, press the right REC button and hold for 3 seconds to enter the force receive mode. All of the clocks hands will now run to zero position (12:00 O'clock) and begin to receive the time signal. If no signal is received then the clock will go back to running the time it was previously according to memory.

Reset

If a pin is inserted to press the reset button at the upper left back of the clock then the clock's hands will run and stop at zero position (12 O'clock). The clock's memory will be cleared and will begin to automatically search for time signal again.



This product contains valuable materials which can be recovered or recycled – please dispose of in accordance with your local council directives

