




Instruction Manual

Electric Patio Heater

Model: OL3966/ OL3967



Please read these instructions carefully before using your new halogen heater

Unpack the halogen heater making sure that all the items are present and that there are no components left in the box and that the heater head is free from any packing material.

Using the detailed drawing and follow the steps to assemble your halogen heater.

Do not connect the halogen heater to the electrical supply until all the assembly is complete.

Do not connect the halogen heater to the electrical supply if any of the components or the power cord is damaged in any way.

If in doubt contact your supplier.

Primrose
info@primrose.co.uk
Tel: 0118 9035210(UK)
Tel: 0044 118 9035210 (outside of UK)

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance. **C**leaning and user maintenance shall not be made by children without supervision.

WARNING: This heater is not equipped with a device to control the room temperature. **Do not** use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

Children of less than 3 years should be kept away unless continuously supervised.

Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

CAUTION — Some parts of this product can become very hot and cause burns. **P**articular attention has to be given where children and vulnerable people are present.

Caution

Only use the halogen heater on a firm solid horizontal area where all the feet on the base are in contact with the floor.

(**S**hould the heater be tilted or fall over the auto cut off switch will activate)

1. **S**ite the heater outside or in a large open area and well away from any obstructions such as branches or where the heater is near any objects that can be effected by heat, such as furniture, curtains or other inflammable

objects (minimum distance 1 metre).

2. **Do not** use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
3. **Do not** use in unventilated areas
4. **Do not** use where gas, petrol, paint or other inflammable goods are stored.
5. **Do not** push any items through, obstruct or cover the grill of the heater head.
6. **Do not** position immediately above or below an electrical socket.
7. **Do not** move when connected to an electrical supply and always wait for the patio heater to cool down before storing away.
8. **Do not** touch the heater head when in use.
9. **Do not** leave turned on and unattended especially when children and or animals are in the vicinity.
10. **T**he indication of the different positions of switches shall be visible from a distance of 1M.
11. **T**he Marking concerning covering shall be visible after the heater has been installed. **I**t shall not be placed on the back of portable heaters.
12. **T**he unit must be placed with the clearance of 100cm to the wall and 30cm to the ceiling.
13. **T**he unit must be correctly installed according to the instructions. **M**ake sure the head is at least 1.8m from the floor.


14. **T**he unit must be securely placed on a horizontal and flat surface.
15. **T**he unit is at high temperature during operation. **I**t keeps hot for a period after shut down. **P**otential danger would occur when touching it during this period.
16. **Don't** place the unit closed to curtain and/or other flammable objects. **O**therwise there will be a danger of catching fire.
17. **Don't** cover the unit with anything during operation or a short time after it's shut down.
18. **Don't** wrap the power supply cord on the unit.
19. **T**he unit must be handled with care, and avoid vibration or hitting.
20. **T**he unit must be securely grounded during operation.
21. **I**f the unit gets damaged, it must be repaired by professional electricians.
22. **W**hen the power supply cord is damaged, it must be replaced by authorized agent or other professional people to avoid danger.
23. **T**he unit must not be positioned under a socket.
24. **When** assembling, keep clear from any board or flammable material.
25. **T**he unit must be supervised by adults if it's used by a child.
26. **Do not** install the unit by a swimming pool, in a bathroom or shower area.
27. **T**he unit is for household use only. **I**t is not safe to use on a building site, greenhouse, barn or stable where there's flammable dust.
28. **T**he head of the unit is at high temperature during operation. **U**nplug the unit and wait till it cools before cleaning.
29. **Don't** use this unit in place where causticity or volatile air exists, i.e. dust, steam, gas, etc.
30. **Don't** use this unit as a cloth drier or towel drier.
31. **Don't** use this unit as a sauna heater.
32. **Don't** use this unit as a room heater.
33. **Don't** use this unit in place of animal propagating and raising.
34. **Don't** immerse this unit into water for cleaning.
35. **T**he unit should be plugged in a socket, which is easily visible and reachable.
36. **T**wo Dark points may exist on the surface of the heating elements during the first few minutes after it is turned on. **T**his is normal, and will not affect the performance of the unit.
37. **A** tilt switch is fitted inside the unit for safety purpose
38. **T**he Wheels are only for the purpose of moving the heater, once the heater is in the right position, the wheels should be removed for safety purpose.

39. **Do not** use this heater with a programmer, timer or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
40. **T**his appliance is not intended for use by persons (including children) with reduced physical. **S**ensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
41. **C**hildren should be supervised to ensure that they do not play with the appliance.


✦ Assembling Process –S.S Base




Warning: Please tear off all the hyaline protect film around the big heater head first!



Step1: Fix the bottom tube onto the stainless steel base by screwing.




Step 2: Connect the middle tube with bottom tube by screwing them together.




Step 3: Connect the top tube with middle tube by screwing them together (as same as Step 3).


Step4: Place the power cord plug through base, bottom pole, middle pole and top pole. Connect the power cord plug to the socket in the heater head.




Step 5: Insert the Heater Head onto the Top Tube and fix in position using the 4*8mm screws.



Step 6: Fix the Power Cord on the Base by using 4*12mm screws.







✧ Assembling Process –Base with painted



Warning: Please tear off all the hyaline protect film around the big heater head before using!




Step 1: Fix the Bottom Tube to the base using 3pcs M6*35 bolts.




Complete!

Step 2: Place the Decoration Cover onto the Bottom Tube.





Step 3: Connect the middle tube with bottom tube by screwing them together.


Step 4 Connect the top tube with middle tube by screwing them together.





Step 5: Place the power cord plug through base, bottom pole, middle pole and top pole. Connect the power cord plug to the socket in the heater head.



Step 7: Insert the Heater Head onto the Top Tube and fix in position using the 4*8mm screws.



Step 8: Fix the Power Cord on the Base.



Complete!

Operation

Connect the power cable to a 13 amp supply that is located in a safe, dry area.

- The switch on the heater head is used to control the three heat setting. (I) for 900w – (II) for 1200w – (I&II) for 2100w. The 0 position is off.
- Although the patio heater is shower proof, do not use when raining or in wet conditions.
- Always disconnect the power cable from the electrical supply, when the patio heater is not in use.

Care and maintenance

- When disconnected from the electrical supply, clean the outside of the patio heater with a damp cloth. Never use corrosive or solvent cleaners or immerse in water.
- Any maintenance or repairs including replacing the halogen tube should only be carried out by a qualified electrician or by a recommended service center.

Technical specification

- Power supply 240V~ 50Hz
- Wattage max 2100w
- Net weight 14kg
- Insulation class I
- Height 230 cm